

How to Maintain Your Door

Monthly:

Check the proper operation of your door by manually moving the door open and closed. If the door binds or sticks, it is out of balance and you should call for garage door service.

Check and test the photo eye safety system of your garage door opener.

Once Every Year:

*Keep the following parts properly lubricated: Lift cables at the bottom bracket, the bearings in the pulleys and/or rollers, your locking hardware where surfaces turn or slide, the full length of the torsion spring (to reduce friction between the coils), the pivot points on every hinge (just a dab), and steel rollers. **DO NOT** lubricate nylon rollers. You should use a light household oil such as Lithium Spray-Lube. You may also use **GIEL SUPER GEL LUBE**.*



Steel doors must be cleaned twice a year. The homeowner should wash and wax steel, aluminum or vinyl doors with a one-step liquid cleaner, found in any auto parts store.